
# Data compression project

Compressing a video using discrete cosine transformation Algorithm



### Names and IDs

Marian Sameh Makram Shendi 20201476313

Rodayna Beshir Hamad 20201503334

Mayar Mohamed Mahmoud Ali 20201382972

Nada Hamdy Fathy Abdelsalam 20201382436

Mayada Elnady Muhammed 20201378363

#### INTRODUCTION

The Discrete Cosine Transform (DCT) algorithm is a mathematical technique used to convert a spatial domain signal, such as an image or video frame, into a frequency domain representation, it reduces redundancy in video data by analyzing and encoding the frequency components.

#### CODE OF APPLYING THE DCT-ALGORITHM ON A VIDEO (MATLAB)

this code reads a video file, extracts its frames, applies DCT-based compression to the frames, and writes the compressed frames to an output video file.

```
clear all;
 close all;
 clc;
  % Read the input video file
 v = VideoReader('v1.mp4');
 % Create a directory to store frames (images)
 working = 'Frames';
 mkdir (working);
 mkdir(fullfile(working, 'images'));
 %ii will be used in the while loop
 ii = 1;
  % Write each frame of the input video to an image file in the working directory
while hasFrame(v)
     img = readFrame(v);
     %imgshow(img) and store the frames as images .png
     filename = [sprintf('%04d', ii),'.png'];
     fullname = fullfile(working, 'images', filename);
     imwrite(img, fullname);
     ii = ii+1;
 end
  % Get the list of image files in the working directory
 imageNames = dir(fullfile(working, 'images','*.png'));
  imageNames = {imageNames.name};
  % Create a video writer object for the compressed output video
 writeObj = VideoWriter(fullfile(working, 'output.avi'));
 vid = VideoReader('v1.mp4');
  % Open the video writer object for writing
 open(writeObj);
```

```
% Loop through each image file in the working directory
for t = 1:length(imageNames)
     Frame = imread(fullfile(working, 'images', imageNames{t}));
     % Resize the image to 512x512 pixels
     n = imresize(Frame, [512, 512]);
     % Apply DCT to each color channel of the image and store the results in
     % matrix z
     Z(:,:,1) = dct2(n(:,:,1));
     Z(:,:,2) = dct2(n(:,:,2));
     Z(:,:,3) = dct2(n(:,:,3));
 % loop through matrix z
    for i = 1:512
         for j = 1:512
             %chick if the rows and cols >60
             if((i+j) > 60)
                 Z(1,j,1) = 0;
                 Z(1,j,2) = 0;
                 Z(1,j,3) = 0;
             end
         end
     end
     % Recovering the bixels using the inverse of dct (icdt) for the channels
     % of the frames
     K(:,:,1) = idct2(Z(:,:,1));
     K(:,:,2) = idct2(Z(:,:,2));
     K(:,:,3) = idct2(Z(:,:,3));
     %Resize the frames to 30% and put the new frames in the opened video
     Frame = imresize(uint8(K), 0.3);
     writeVideo(writeObj, Frame);
-end
 %Close the video writer object
 close(writeObj);
```

#### **USED FUNCTIONS**

- 1. VideoReader(): It reads an input video file
- 2. **readFrame()**: it reads each frame from the video
- 3. **imwrite()**: used to save the frames as PNG images
- 4. **imread()**: It reads an image frame from directory
- 5. **imresize**(): It resizes the image frame

- 6. **dct2()**: applies the DCT (Discrete Cosine Transform)
- 7. writeVideo(): it writes the compressed frame to the VideoWriter object

#### PSEUDO CODE

```
clear all
close all
clc
v <- OUTPUT openreadvideo('video.extension of video)
working <- 'frames'
OUTPUT makedirection(working)
OUTPUT makedirection (OUTPUT fullfile (working, 'images'))
ii<-1
while hasframed[v]
 img<- OUTPUT readframe(v)</pre>
 filename <- display in next line ('%04d',ii),.
                                                   extension of photos)
  fullname <- OUTPUT fullfile(working,'images', filename)</pre>
 OUTPUT WriteImagesInFormat(img, fullname)
 ii<-ii+1
Endloop
Imgnames <- directory (OUTPUT fullfile(working, 'images', '*. extension of photos))
Imgnames <- [imgnames.names]</pre>
writeObj <- OUTPUT videowriter(fullfile (working , output.avi)</pre>
Vid <- openreadvideo (video.extension of video)
open(writeobj)
```

```
for t=1 to length(imagenames)
 Frame <- OUTPUT WriteImagesInFormat (OUTPUT fullfile (working, 'images',
imagenames (t)))
 n<- OUTPUT imgsize(frame,scale[width,hight])</pre>
Z(:,:,1)= OUTPUT 2d discrete cosine transform(n,(:,:,1))
 Z(:,:,2)= OUTPUT 2d discrete cosine transform(n,(:,:,2))
Z(:,:,3)= OUTPUT 2d discrete cosine transform(n,(:,:,3))
 for i=1 to 512
   for j=1 to 512
    if((i+j)>60))
       Z(1,j, 1)=0
       Z(1,j,3)=0
        Z(1,j,4)=0
    Endif
  Enfor
Endfor
K(:,:,1)=OUTPUT inverse of 2d discrete cosine transform z(:,:,1))
K(:,:,2)=OUTPUT inverse of 2d discrete cosine transform z(:,:,2))
K(:,:,3)=OUTPUT inverse of 2d discrete cosine transform z(:,:,3))
frame <- imgsize(unit8(k), scale)
Write video (writeObj ,frame)
Endfor
Close(writeobj)
```

## COMPARISON BETWEEN VIDEO CHARACTERISTICS BEFORE AND AFTER COMPRESSION

POINT OF COMPARISON	BEFORE	AFTER
Bitrate: the amount of data that is required to represent one second of video	1179 kbps	802 kbps
Frame: a still image that represents a single moment in time in the video sequence	179	176
Ratio aspect: relationship between the width and height of the video frame	(1:1.78/1:1.78)	(1:1/1:1)
Resolution: refers to its pixel dimensions, usually expressed as the number of pixels in the height and width of the video frame	576 x 1024	154 x 154
Size	848 KB	605 KB